

Answer:

c. remove patients from the area, notify everyone in the vicinity, seal the area, do not decontaminate the area unless absolutely necessary

Key issues with this question and answer: Because most Nuclear Cardiology spills are major, it is best not attempt decontamination. The safety of the patient is paramount, and removing them from additional unnecessary radiation exposure must be the top priority.